

1 CONNECT TO A PC

Download the HauteVIEW management utilities from our website at www.hautespot.net. Once the drivers and software are installed, connect the HauteVIEW100 camera to the PC using the provided USB cable directly into the camera's USB port or by docking the camera to the provided docking accessory.

2 DEVICE ID & PASSWORD

Open "CAM Manager", and click "Connect Device". If you get an alert that says the device is not connect, make sure to follow the Driver & Software Installation instructions and/or disconnect the camera from the PC and reconnect it, then click the "Connect Device" button again.

The default password is **000000** (6 zero's). Click "Connect". You should get an alert that the time was set successfully. If not, check to see that your computer's system date and time are configured correctly. This software will allow you to set the camera's date and time using "Device Time", change the Device ID and Police ID, change the password and allow you to enter U disk mode which allows the PC to view the camera as a mass storage device for data management purposes. Once you have configured your camera, click "Return" then click "Disconnect Device". Proceed to step 3 to power on the device.

3 POWER ON & RECORDING

Please fully charge the HauteVIEW100 prior to first use.

To power on the device after it has been fully charged, press and hold **[Power]** button for 3 seconds until you hear the boot up chime. The camera will say out loud the Police ID configured for the camera (default is 000000) and begin recording automatically. To stop recording, press **[Stop]** button. The camera will announce that recording has stopped and will vibrate to confirm.

4 RECORD VIDEO























To begin video recording, press **[Start]** button. The camera will announce that it has begun recording and vibrate. To stop recording video, press **[Stop]** button. To access the recorded video clips, click **[OK]**. Using the **[Left]** and **[Right]** buttons for navigation, highlight VIDEO and press **[OK]**. You can navigate to the desired video clip by using the **[Left]** and **[Right]** buttons. Press **[OK]** on the clip you wish to play. It will automatically begin playing. Press **[OK]** to pause and play the video. Press **[Power]** to return to the File Navigation Screen, and once more to return to the Main Screen.

5 CHARGING

Turn off the camera before charging

Use the provided USB cable/dock, car charger, or wall wart charging accessories to charge the camera. The Li-ion rechargeable battery takes 4 hours to fully charge from a discharged state. The indicator light located next to the **[Power]** will glow blue to show that it is charging.

BASIC KEY FUNCTIONS

-  Power on/off and lock/unlock key- long press to boot, long press it again to turn off, short press to lock the screen, short press it again to unlock. In Menu mode, this is the back key.
- Indicator light  : Standby
Indicator light  : Charging
Indicator light  : Video recording and flashing
Indicator light  : Audio recording and flashing
- Reset key - located inside of the HDMI area
-  Play/up key - Short press
-  Play back key - Short press for the last audio & video file. While in menu, up and left key
-  Fast reverse key - Short press for 2X, 4X, 8X, 16X, 32X , 64X
-  OK/Confirm key - Short press
-  Laser pointer key - Long press to open and long press again to turn off
-  Event marker key - Long press for traffic control, criminal investigation, general public safety, or none. (4 modes)
-  Pus-to-Talk key - Short press connect to the walkie-talkie
-  Menu key- Short press for interface setting, selecting and browsing files
-  Zoom key - Long press to zoom-in
-  Fast forward & reverse key - Short press for 2X, 4X, 8X, 16X, 32X , 64X
-  Audio recording key - Long press to start and long press to stop when the camera is turned off. Short press to start and stop audio when camera is on.
-  Resolution change key - Long press to change the resolution to 480 or 720 (Note: Can't return to 1080P using this key)
-  Photo key - Short press
-  LED flash light key - Long press
-  Video recording key - Long press to start and long press to stop when the camera is turned off. Short press to start and stop when camera is on.
-  Snap shot key - Short press for getting one photo during video recording
-  Infrared mode/light control key - Long press for flash light.
Short press IR on/off.

- Please fully charge before first use.
- To avoid short circuit during use, please keep the bottom of the camera from sitting in water

HAUTESPOT®

Networks

Where the network ends, we began™

HauteVIEW

Quick Start V.1.3

HauteVIEW 100	Parameter
Max Still Resolution	21 Megapixels
Video Resolution	1920 x 1080 30P 1440 x 1080 30P 1280 x 720 60P/1280 x 720 30P 848 x 480 60P/848 x 480 30 P 720 x 480 30 P 16:9
Display Screen	2 inch TFT-LCD HD Clear color display screen
Lens	140° wide-angle lens, non-distorting
Memory Capacity	Build-in 32GB
Data Interface	HDMI 1.3 Supports 1080P TV Output/NTSC
Continuous Recording Time	10 hours
Shoulder Microphone	Supports all kinds of PTT LMR radios
Positioning System	GPS (Optional)
Car Mount	Supported
External Power Supply	Supported

www.hautespot.net
Phone: 805-541-9477
P. O. Box 4016, San Luis Obispo, CA 93403